# SAJ





# **B3-5.0-LV**



GUANGZHOU SANJING ELECTRIC CO., LTD

Tel: (86)20 66608588 Fax: (86)20 66608589 Web: www.saj-electric.com Add: SAJ Innovation Park, No.9, Lizhishan Road, Science City, Guangzhou High-tech Zone , Guangdong, P.R.China

V2.0





# B3-5.0-LV Operation Manual

## **CONTENTS**

1	Technic	al Data		1-2		
2	Product	Overview		3		
	2.1	Brief Introdu	iction	3		
	2.2	Interface Int	4			
	2.2.1	Switch ON/0	DFF	4-5		
	2.2.2	LED Indicat	or Definition	5-6		
	2.2.3	CAN / RS48	35 Port	6		
	2.2.4	RS232 Port		6		
3	Installat	ion Guide		7		
	3.1	Checking B	efore Installation	7		
	3.1.1	Checking O	7			
	3.1.2	Checking D	eliverables	7-8		
	3.2	Tools		9		
	3.3	Installation	requirements	9		
	3.3.1	Installation	environment requirements	9		
	3.3.2	Installation	carrier requirements	9		
	3.4	4 Installation Instructions				
	3.4.1	Dimensions				
	3.4.2	Installation	Procedure	11-16		
4	Mainter	nance		17		
	4.1	Recharge R	equirements During Normal Storage	17		

mannen	
4.1	Recharge Requirements During Normal Storage
4.2	Recharge Requirements When Over Discharged

18



## TECHNICAL DATA

#### NOTE

Operating current derating according to cell voltage and battery temperature.



Performance						
Nominal Voltage	51.2 Vdc					
Nominal Capacity	100Ah					
Battery Energy	5120 Wh					
Operating Voltage	44.8-56.16Vdc					
Nominal Charge/Discharge Current	50A					
Nominal Charge/Discharge Power	2560W					
Max Charge / Discharge Current	100A					
Max Charge / Discharge Power	5120W					
Short Circuit Current	350A/5mS					
	Communication					
Display	SOC status indicator, LED indicator					
Communication	RS232, RS485, CAN					
	General Specification					
Dimension(W×D×Hmm)	494X500X145mm					
Weight (Kg)	43kg±2					
Installation	Floor stand or Wall mounted					
Charging Temperature Range	0°C to +55°C					
Discharge Temperature Range	-20°C to +60°C					
Operating humidity	≤95%RH					
Max Operating Altitude	≤2000m					
IP Rating	IP21					
Cell Technology	6000 Cycles					
Scalability	Max 15 batteries in parallel					
Certification	IEC 61000, IEC62619, UN38.3					

1. Test conditions: 80% depth of discharge (DoD), 0.2C rate charge & discharge at 25°C.

2. Charge/discharge derating occurs when the operating temperature from -10  $^\circ$  C to 5  $^\circ$  C. & 45  $^\circ$  C to 55  $^\circ$  C.

3. Condition apply. Refer to B3-5.0-LV Warranty Letter



### **PRODUCT OVERVIEW**

#### 2.1 Brief Introduction



PRODUCT OVERVIEW

B3-5.0-LV is a lithium battery with an operating voltage range between 44.8-56.16V. It is designed for residential energy storage applications and works together with a 48v battery hybrid inverter. **B3-5.0-LV is not suitable for supporting life-sustaining medical devices.** 

B3-5.0-LV has built-in BMS (Battery Management System), which can manage and monitor cells information including voltage, current and temperature. Besides that, BMS can balance cells charging to extend cycle life. BMS has protection functions including over-discharge, over-charge, over-current and high/low temperature; the system can automatically manage charge state, discharge state and balance state.

Multiple B3-5.0-LV can be connected in parallel to expand capacity and power, B3-5.0-LV can be connected in parallel at most.

#### **2.2** Interface Introduction







#### 2.2.1 Switch ON/OFF

#### 1. Switch ON

Turn on a single B3-5.0-LV ,turn on the air switch, then press the circular weak current switch (more than 3 seconds) on / off button, the LED flashes and the battery works normally. L1 to L6 display the battery SOC,L7/L8 to indicate the battery status.

For multiple B3-5.0-LVin parallel, switch ON circular weak current switch on all batteries, long press (more than 3 seconds) ON/OFF button of MASTER battery, LED will flash. battery system will automatically encode and assign ID to each slave battery, then battery system will operate normally.

#### 2. Switch OFF

Press the Circular weak current switch of the master pack for more than 3 seconds and then release the button. When all slave pack are closed, the master pack will be closed (sleep mode). For a single B3-5.0-LV, turn off the Circular weak current switch. For multiple B3-5.0-LVin parallel, turn off the Circular weak current switch on the main battery first. Then turn off the Circular weak current switch on all subordinate batteries

#### 2.2.2 LED Indicator Definition

#### Note:

flash 1 - 0.25s light / 3.75s off flash 2 - 0.5s light / 0.5s off flash 3 - 0.5s light / 1.5s off

#### LED Indicators Instructions

		RUN	ALM		E	Battery Lev	el Indicato	r		
		L8	L7	L6	L5	L4	L3	L2	L1	
Status										Descriptions
Shut dow	n	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	All OFF
Standby		Flash 1	OFF		Ad	ccording to	the battery	/ level		Indicates Standby
Charaina	Normal	Light	OFF		Ad	ccording to	The highest capacity indicator LED flashes(flash			
Charging	Full Charged	Light	OFF	Light	Light	Light	Light	Light	Light	2),others lighting Turn to standby status when charger off
	Protection	OFF	Light	OFF	OFF	OFF	OFF	OFF	OFF	Stop charging
Normal Flash 3 OFF			Ad	ccording to						
Discharg	UVP	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Stop charging
	Protection	OFF	Light	OFF	OFF	OFF	OFF	OFF	OFF	Stop discharging
Fault		OFF	Light	OFF	OFF	OFF	OFF	OFF	OFF	Stop charging and Discharging

Charging Battery Level Indicators Instructions

Stat	Charging								
Batteny Level Ir	dicator	L8	L7	L6	L5	L4	L3	L2	L1
Battery Levern	laleator								
	0~ 17%			OFF	OFF	OFF	OFF	OFF	Flash 2
	18~33%	Light	OFF	OFF	OFF	OFF	OFF	Flash 2	Light
Battery Level	34 ~50%			OFF	OFF	OFF	Flash 2	Light	Light
	51 <b>~</b> 66%			OFF	OFF	Flash 2	Light	Light	Light
	67 <b>~</b> 83%	]		OFF	Flash 2	Light	Light	Light	Light
	84 <b>~</b> 100%	]		Flash 2	Light	Light	Light	Light	Light
	Full Charged			Light	Light	Light	Light	Light	Light

#### Discharging Battery Level Indicators Instructions

Statu	Discharge								
		L8	L7	L6	L5	L4	L3	L2	L1
Battery Level I	ndicator								
	0~17%			OFF	OFF	OFF	OFF	OFF	Light
	18~33%			OFF	OFF	OFF	OFF	Light	Light
Battery Level	34~50%	Flash 3	OFF	OFF	OFF	OFF	Light	Light	Light
(%)	51 <b>~</b> 66%			OFF	OFF	Light	Light	Light	Light
	67 <b>~</b> 83%			OFF	Light	Light	Light	Light	Light
	84 <b>~</b> 100%			Light	Light	Light	Light	Light	Light

#### 2.2.3 CAN / RS485 Port

CAN / RS485 Communication Terminal (RJ45 port), connect to inverter, follow CAN / RS485 protocol.

PIN	Definition
Pin 1、Pin 8	RS485-B ( to PCS, reserved )
Pin 2、Pin 7	RS485-A ( to PCS, reserved )
Pin 3	NC
Pin 4	CANH ( to PCS )
Pin 5	CANL ( to PCS )
Pin 6	GND

#### 2.2.4 RS232 Port

RS232 Communication Terminal (RJ45 port) follow RS232 protocol, for manufacturer or professional engineer to debug or service.

PIN	Definition
Pin 1、Pin 8	GND
Pin 2√ Pin 7	RS232_TX
Pin 3、Pin 6	RS232_RX
Pin 4、Pin 5	NC



# INSTALLATION GUIDE



#### 3.1 Checking Before Installation

#### 3.1.1 Checking Outer Packing Materials

Packing materials and components may be damaged during transportation. Therefore, check the outer packing materials before installing the battery. Checking the surface of packing materials for damage, such as holes and cracks. If any damage is found, do not unpack the battery and contact the dealer as soon as possible. You are advised to remove the packing materials within 24 hours before installing the battery.

#### 3.1.2 Checking Deliverables

After unpacking the battery, check whether deliverables are intact and complete. If any damage is found or any component is missed, contact the dealer.

The below table shows the components and mechanical parts that should be delivered.



No.	Pictures of accessories	2VBOUJU	Uses	No.	Pictures of accessories	2VBOUJU	Uses
1	•	1	Battery box	8		2	Foot pads
2		1	Wall mounting bracket	9		4	RJ45 Crystal head
3		2	Hanging bracket	10	0	2	Communication network cable
4		8	Fixed box	11	LIVESTIGATE as a loss off construction VOTES LIVESTIGATION LI	2	Desiccant
				12		1	User manual
5		4	Lock Wall Pendant	13		1	Outgoing Inspection Report
6		1	Grounding screw	14	©. <b>2</b>	1	Power wire, one end SC25-8, AWG4#PVC wire 3512, L=1500mm, black;
7		2	Foot cushion screws	15		1	Power wire, one end SC25-8, AWG4EPVC wire 3512, L=1500mm, red;



Tools							
	Knife	Measuring tape	Socket wrench (10/16mm)				
Installation	Rubber mallet	Cross Screwdriver	Hammer drill (10mm)				
	ESD gloves	Safety goggles	Anti-dust respirator				
Protection	Safety shoes						

#### 3.3 Installation requirements

#### 3.3.1 Installation environment requirements

- Install the battery in the indoor environment.
- Place battery in secure location away from children and animals.
- Do not place the battery near any heat sources and avoid sparks.
- Do not expose the battery to moisture or liquids.
- Do not expose the battery to direct sunlight.

#### 3.3.2 Installation carrier requirements

- Only mount battery on fire resistant building. Do not install batteries on flammable buildings.
- Battery is quite heavy, make sure the wall/ground can meet the load bearing requirements.



Minimum mounting distance between battery pack and equipment:



#### 3.4.2 Installation Procedure

#### STEP 1

Drill the hole with an 10mm drill bit as follows and fix the wall bracket to the wall.



#### **STEP 3** Hang B3-5.0-LV on the wall bracket and tighten it.







**STEP 4** Connect to ground.







#### STEP 6

Connect communication cable.



#### STEP 7

1. Load power exceeding 5kW requires at least 2 units Parallel operation.

2. The maximum number of Number of parallel machines is 15. The power of the inverter selected for the battery module must be less than the maximum output power of the battery module.

Parallel operation	Load power	Connection mode
1unit	Below 5kW	7.1
2-15units	Below 5kW	7.2
2-15units	Over 5kW	7.3

<b>Danger</b>	Ensure power cables are installed with the correct polarity. A dangerous situation may arise if the polarities are reversed.
<b>Danger</b>	Do not create a short circuit between the positive and negative terminals of the battery. Ensure the polarity is correct during installation.
Warning	Incorrect communication cable connection will cause the battery system to operate in unexpected ways which may lead to system failure.







#### **Warning**

- For a 2-unit to 15-unit layer module with power below 5 kW. (The number of units in the middle of the diagram is omitted. The lengths of the two positive and negative pole connecting lines must be the same. Recommendation:
- 7.2 To ensure overcurrent protection, a 125A-rated circuit breaker shall be installed in the power cable harness between the battery pack and the inverter. For systems utilizing SAJ's 10kW inverter in this parallel configuration, the charge/discharge current must be explicitly limited to ≤100A within the inverter's battery parameter settings.

	▲ Warning
7.3	When using an inverter of 10kW or above, the positive and negative ports of each battery must be connected to the combiner cabinet in the wiring method shown in the figure below. For 2 units -15 units is Over 10kW. (The number of units in the middle of the diagram is omitted.In order to ensure equal current flow, the length of the positive and negative poles connecting lines must be the same.) For this parallel connection configuration, when using SAJ's 10kW inverter for battery charging/discharging: Cable Requirements: The power cable harness between the combiner box and inverter shall use copper cables with: Current-carrying capacity ≥240A,Conductor size ≥2/0 AWG Protection Requirement: A 250A-rated circuit breaker must be installed to provide overcurrent protection.







## MAINTENANCE

#### 4.1 Recharge Requirements During Normal Storage

Battery should be stored in an environment with temperature range between -10°C ~+45°C, and maintained regularly according to following table with 0.5C (50A) current till 40% SOC after long storage time.

#### **Recharge Conditions When In Storage**

Storage Environment Temperature	Relative Humidity of Storage Environment	Storage Time	SOC
Below -10°C	/	prohibit	/
-10~25°C	5%~70%	≤12 months	30%≤SOC≤60%
25~35℃	5%~70%	≤6 months	30%≤SOC≤60%
35~45℃	5%~70%	≤3 months	30%≤SOC≤60%
Above 45℃	/	prohibit	/

#### 4.2 Recharge Requirements When Over Discharged

Over discharged (90% DOD) battery should be recharged according to following table, otherwise over discharged battery will be damaged.

#### Recharge conditions when battery is over discharged

Storage Environment Temperature	Storage Time	Note
-10~25℃	≤15 days	Battery Pack
25~35℃	≤7 days	disconnected from to Inverter
35~45℃	<12 hours	Battery Pack connected to Inverter